Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.

SAMSUNG ELECTRONICS

Printed in Korea
Code No.:GH68-28721A
English (LTN). 04/2010. Rev. 1.0

www.samsungmobile.com

GT-S3370L

user manual

SAMSUNG

Using this manual

Thank you for purchasing this Samsung mobile phone. This phone will provide you with high quality mobile communication and entertainment based on Samsung's exceptional technology and high standards.

This user manual has been specially designed to guide you through the functions and features of your phone.

- Please read this manual carefully before using your phone to ensure safe and correct use.
- The descriptions in this manual are based on the default settings of your phone.
- Please keep this manual for future reference.

Instructional icons

Before you start, familiarize yourself with the icons you will see in this manual:

Warning—situations that could cause injury to yourself or others

Caution—situations that could cause damage to your phone or other equipment

Note—notes, usage tips, or additional information

► **Refer to**—pages with related information; for example: ► p. 12 (represents "see page 12")

→ **Followed by**—the order of options or menus you must select to perform a step; for example: In Menu mode, select **Messages** → **Create message** (represents **Messages**, followed by **Create message**)

[ ] **Square brackets**—phone keys; for example: [📷] (represents the Camera key)

Copyright information

Rights to all technologies and products that comprise this phone are the property of their respective owners:

- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide.
  Bluetooth QD ID: B016433
- Java™ is a trademark of Sun Microsystems, Inc.
- Windows Media Player® is a registered trademark of Microsoft Corporation.

Contents

Assembling 7
- Unpack 7
- Install the SIM or USIM card and battery 7
- Charge the battery 9
- Insert a memory card (optional) 11
- Attach a hand strap (optional) 13

Getting started 14
- Turn your phone on and off 14
- Get to know your phone 14
- Use the touch screen 17
- Lock or unlock the touch screen and keys .. 18
- Access menus 18
- Launch and manage applications 19
- Use widgets 20
- Customize your phone 21
- Enter text 26
- Access help information 28

Communication 29
- Calling 29
- Logs 32
- Messages 34
- Chat 40

Entertainment 41
Camera 41
Music 44
Find music 45
FM radio 46
Games 47

Personal information 48
Phonebook 48
Calendar 50
Task 51
Memo 52
Voice recorder 52

Web 53
Internet 53
RSS reader 54
Samsung Apps 55
Google 56
Synchronize 56
ActiveSync 57
Communities 58

Connectivity 60
Bluetooth 60
PC connections 63

Tools 65
Alarms 65
Calculator 65
Convertor 66
Image editor 66
My files 68
Stopwatch 68
Timer 69
World clock 69

Settings 70
Access the Settings menu 70
Phone profiles 70
Display and light 70
Time and date 70
Phone settings 71
Smart unlock 71
Touch panel 71
Application settings 71
Security 72
Network settings 73
Memory settings 73
Reset settings 73

Troubleshooting 74

Safety and usage information 78

Index 86

Assembling

Unpack

Check your product box for the following items:

- Mobile phone
- Battery
- Travel adapter (charger)
- User manual

Use only Samsung-approved software. Pirated or illegal software may cause damage or malfunctions that are not covered by your manufacturer's warranty.

- The items supplied with your phone may vary depending on the software and accessories available in your region or offered by your service provider.
- You can obtain additional accessories from your local Samsung dealer.
- The supplied accessories perform best for your phone.

Install the SIM or USIM card and battery

When you subscribe to a cellular service, you will receive a Subscriber Identity Module (SIM) card, with subscription details, such as your personal identification number (PIN) and optional services. To use UMTS or HSDPA services, you can purchase a Universal Subscriber Identity Module (USIM) card.

To install the SIM or USIM card and battery,

1 If the phone is on, press and hold the Power/End key to turn it off.

2 Remove the back cover.



Be careful not to damage your fingernails when you remove the back cover.

3 Insert the SIM or USIM card.



- Place the SIM or USIM card into the phone with the gold-colored contacts facing down.
- If you do not insert a SIM or USIM card, you can only use your phone's non-network services and some menus.

4 Insert the battery.



5 Replace the back cover.



Charge the battery

Before using the phone for the first time, you must charge the battery.

You can charge the phone with the provided travel adapter or by connecting the phone to a PC with a PC data cable.

Use only Samsung-approved chargers and cables. Unauthorized chargers or cables can cause batteries to explode or damage your phone.

When your battery is low, the phone will emit a warning tone and display a low battery message. The battery icon will also be empty and blinking. If the battery level becomes too low, the phone will automatically power off. Recharge your battery to continue using your phone.

Charge with the travel adapter

1. Open the cover to the multifunction jack on the side of the phone.
2. Plug the small end of the travel adapter into the multifunction jack.



Improperly connecting the travel adapter can cause serious damage to the phone. Any damages due to misuse are not covered by the warranty.

3. Plug the large end of the travel adapter into a power outlet.

- You can use the phone while it is charging, but it may take longer to fully charge the battery.
- While charging, the phone may heat up. This is normal and should not affect your phone's lifespan or performance.
- If your phone is not working properly, bring your phone and the charger to a Samsung Service Center.

4. When the battery is fully charged (the battery icon is no longer moving), unplug the travel adapter from the phone and then from the power outlet.

Do not remove the battery before removing the travel adapter. Doing this may cause damage to the phone.

› Charge with the PC data cable

Before charging, ensure that your PC is turned on.

1. Open the cover to the multifunction jack on the side of the phone.
2. Plug one end (micro USB) of the PC data cable into the multifunction jack.
3. Connect the other end of the PC data cable into a USB port on a PC.

   Depending on the type of PC data cable you are using, it may take some time before charging begins.
4. When the battery is fully charged (the battery icon is no longer moving), unplug the PC data cable from the phone and then from the PC.

Insert a memory card (optional)

To store additional multimedia files, you must insert a memory card. Your phone accepts microSD™ or microSDHC™ memory cards with maximum capacities of 8 GB (depending on memory card manufacturer and type).

Samsung uses approved industry standards for memory cards, but some brands may not be fully compatible with your phone. Using an incompatible memory card may damage your phone or the memory card and can corrupt data stored on the card.

- Your phone supports only the FAT file structure for memory cards. If you insert a card formatted with a different file structure, your phone will ask you to reformat the memory card.
- Frequent writing and erasing of data will shorten the lifespan of memory cards.

1 Remove the back cover.

2 Insert a memory card with the gold-colored contacts facing down.



3 Replace the back cover.

Remove the memory card

1 Ensure that the memory card is not in the middle of an operation.

2 Remove the back cover.

3 Push it gently until it disengages from the phone, and then pull the memory card out of the memory card slot.

Do not remove a memory card while the phone is transferring or accessing information, as this could result in loss of data or damage to the memory card or phone.

4 Replace the back cover.

Format the memory card

Formatting your memory card on a PC may cause incompatibilities with your phone. Format the memory card only on the phone.

In Menu mode, select **Settings** → **Memory settings** → **Memory card settings** → **Format** → **Yes**.

Before formatting the memory card, remember to make backup copies of all important data stored in your phone. The manufacturer's warranty does not cover loss of data that results from user actions.

Attach a hand strap (optional)

1 Remove the back cover.

2 Slide a hand strap through the hand strap hole and hook it over the small projection.

3 Replace the back cover.

Getting started

Turn your phone on and off

To turn on your phone,

1. Press and hold the Power/End key.
2. Enter your PIN and select **Confirm** (if necessary).

To turn off your phone, repeat step 1 above.

- Follow all posted warnings and directions from official personnel when in areas where the use of wireless devices is restricted, such as airplanes and hospitals.
- To use your phone's non-network services only, switch to the offline profile. ► p. 22

Get to know your phone

› Phone layout





Keys

Key	Function
Dial	Make or answer a call; In Idle mode, retrieve recently dialled, missed, or received numbers.
Back	In Menu mode, return to the previous level; Return to the main menu without closing a menu or application (press and hold).
Power/End	Turn the phone on or off (press and hold); End a call; In Menu mode, return to Idle mode.
Volume	Adjust the phone's volume; In Idle mode, press and hold the Volume key down to make a fake call.
Lock	Lock the touch screen and keys; Unlock the touch screen and keys (press and hold).

Key	Function
Camera	In Idle mode, turn on the camera; In Camera mode, take a photo or record a video.

Indicator icons

Icons shown on the display may vary depending on your region or service provider.

Icon	Definition
	Signal strength
	GPRS network connected
	EDGE network connected
	UMTS network connected
	Voice call in progress

Icon	Definition
	Video call in progress
	SOS message feature activated
	Browsing the web
	Connected to secured web page
	Roaming (outside of normal service area)
	Call diverting activated
	Connected with PC
	Bluetooth hands-free car kit or headset connected
	Bluetooth activated
	Alarm activated

Icon	Definition
	Memory card inserted
	New text message (SMS)
	New multimedia message (MMS)
	New email message
	New voice mail message
	Normal profile activated
	Silent profile activated
	Battery power level
10:00 AM	Current time

Use the touch screen

Your phone's touch screen lets you easily select items or perform functions. Learn basic actions to use the touch screen.

- To avoid scratching the touch screen, do not use sharp tools.
- Do not allow the touch screen to come in contact with other electrical devices. Electrostatic discharges can cause the touch screen to malfunction.
- Do not allow the touch screen to come in contact with water. The touch screen may malfunction in humid conditions or when exposed to water.

For optimal use of the touch screen, remove the screen protection film before using your phone.

Control your touch screen with the following actions:

- Tap: Tap once with your finger to select or launch a menu, option, or application.
- Double-tap: Tap twice quickly with your finger to zoom in or out while viewing photos or web pages.
- Drag: Tap and hold your finger on an item, and then drag your finger to move the item.
- Scroll: Tap and drag your finger up, down, left, or right to move to items on lists.

Your phone turns off the touch screen when you do not use the phone for a specified period. To turn on the screen, press any key.

Lock or unlock the touch screen and keys

You can lock the touch screen and keys to prevent any unwanted phone operations.

To lock, press the Lock key. To unlock, press and hold the Lock key. Alternatively, press the Lock key and tap and hold the lock icon.

You can also set the phone to automatically lock the touch screen and keys when you do not use the phone for a specified period. In Menu mode, select **Settings** → **Touch panel** → **On** under **Auto-lock** → **Save**.

Access menus

To access your phone's menus,

1. In Idle mode, select **Menu** to access Menu mode.
2. Scroll left or right to a main menu screen.

3 Select a menu or application.

4 Press the Back key to move up one level; Press the Power/End key to close the menu or application and return to Idle mode.

› Organize applications in Menu mode

You can reorganize the applications in Menu mode by changing their order or grouping them into categories to suit your preferences and needs.

1 In Idle mode, select **Menu** to access Menu mode.

2 Select **Edit** at the top left of the screen.

3 Drag an application icon to the location you want.

You can move an application icon to another main menu screen.

4 Select **Save** or **Done**.

Select **Reset** to initialize the main menu screens.

Launch and manage applications

› Launch multiple applications

Your phone allows you to multi-task by running multiple applications at the same time.

To launch multiple applications, press and hold the Back key and select an application to launch.

You may incur additional charges for data connection while Instant messenger is running in the background.

› Use the task manager

You can manage multiple applications with the task manager.

To launch the task manager, in Menu mode, select **Task mgr**. The list of active applications appears.

To change the view mode, select **List view** or **3D view**.

Control active applications as follows:

- To switch between applications, select one from the list of active applications.
- To close an application, select ⊖.
- To close all applications, select **End all applications**.

Use widgets

Widgets are small applications that provide convenient functions and information on your idle screen.

- Some of your widgets connect to web services. Using a web-based widget may incur additional charges.
- Available widgets may vary depending on your region or service provider.

› Open the widget toolbar

To open the widget toolbar and access widgets,

1. In Idle mode, select the arrow at the bottom left of the screen to open the widget toolbar.
2. Scroll up or down on the widget toolbar to find the widget you want to use.
3. Drag the widget to the idle screen or select the widget to activate it on the idle screen.

   To move the widget back to the widget toolbar, drag it to the position you want on the widget toolbar.

You can organize each panel of the idle screen with your favorite widgets. Scroll left or right to a panel and then position widgets anywhere on the screen.

View or change widgets

You can view widget names or select widgets to include on the widget toolbar.

1. Open the widget toolbar and select .
   The marked widgets are available from the widget toolbar.
2. Select the widgets you want to include on the widget toolbar.
3. Select **Save**.

Download new widgets

1. Open the widget toolbar and select .
2. Select an option to search for widgets.
   You can also enter a keyword in the input field and select .
3. Scroll through the widget list and select a widget to download.
   When downloading is complete, the widget will be automatically added to the widget toolbar.

If the widget toolbar is full, downloaded widgets will not be automatically added to the widget toolbar. You must remove some widgets from the toolbar and add the new widgets manually.

Customize your phone

Get more from your phone by customizing it to match your preferences.

Set the current time and date

1. In Menu mode, select **Settings** → **Time and date**.
2. Select the time zone updating option and a time zone.

3 Set the time and date format, and enter the current time and date.

4 Select **Save**.

Adjust the volume of the key tones

In Idle mode, press the Volume key up or down.

Adjust the vibration intensity of the touch screen

You can adjust the intensity of the vibration feedback that results when you tap the phone screen.

1 In Menu mode, select **Settings** → **Phone settings** → **Vibration feedback**.

2 Drag the slider to adjust the vibration intensity of the touch screen.

3 Select **Save**.

Switch to the silent profile

In Idle mode, select **Keypad**, and then tap and hold # to mute or unmute your phone.

Set up a sound profile

You can change your phone's sounds by customizing the current sound profile or switching to another sound profile. To set up a profile,

1 In Menu mode, select **Settings** → **Phone profiles**.

2 Select » next to the profile you are using.

3 Customize the sound options for incoming calls, incoming messages, and other phone sounds.

Available sound options vary depending on the selected profile.

4 Select **Save**.

To switch to another profile, select it from the list.

Select a wallpaper for the idle screen

You can select separate wallpapers for each panel of the idle screen.

1. In Idle mode, scroll left or right to one panel of the idle screen.
2. In Menu mode, select **Settings** → **Display and light** → **Wallpaper**.
3. Scroll left or right to an image.
   To select an image from the image folder, select **Images**.
4. Select **Set**.

Adjust the brightness of the display

The brightness level of the display will affect how quickly the phone consumes battery power.

1. In Menu mode, select **Settings** → **Display and light** → **Brightness**.
2. Drag the slider to adjust the level of brightness.
3. Select **Save**.

Calibrate the touch screen

You can calibrate the screen so that your phone recognizes your inputs better.

1. In Menu mode, select **Settings** → **Phone settings** → **Calibration**.
2. Tap the target on the screen until the calibration is finished.
3. Select **Yes**.

Unlock the touch screen with gestures

With the smart unlock feature, you can unlock the touch screen by drawing a specified character on the locked touch screen. To set an unlock gesture,

1. In Menu mode, select **Settings** → **Smart unlock**.
2. Select **On** under **Gesture unlock**.
3. Select an unlock option.

   You can set the phone to unlock only, unlock and then make a call to a speed dial number, or unlock and then launch an application.

   If you set the phone to unlock only, skip to step 5.
4. Select a speed dial number to dial and a contact, or select an application to launch.
5. Select a gesture (A to Z) for the smart unlock feature.

   To select a language for gestures, select **Change language**.

   If you set the phone to unlock only, skip to step 7.
6. Press the Back key.
7. Select **Save**.

To unlock the touch screen, press any key and draw the gesture that corresponds to the unlock feature you want.

Lock your phone

You can lock your phone by activating the phone password.

1. In Menu mode, select **Settings** → **Security**.
2. Select **On** under **Phone lock**.
3. Enter a new 4- to 8-digit password and select **Confirm**.
4. Enter the new password again and select **Confirm**.

The first time you access a menu that requires a password, you will be prompted to create and confirm a password.

Once the phone lock is enabled, you must enter the password each time you turn on the phone.

- If you forget your password, bring your phone to a Samsung Service Center to unlock it.
- Samsung is not responsible for any loss of passwords or private information or other damages caused by illegal software.

Lock your SIM or USIM card

You can lock your phone by activating the PIN supplied with your SIM or USIM card.

1. In Menu mode, select **Settings** → **Security**.
2. Select **On** under **PIN lock**.
3. Enter the PIN of your SIM or USIM card and select **Confirm**.

Once the PIN lock is enabled, you must enter the PIN each time you turn on the phone.

- If you enter an incorrect PIN too many times, your SIM or USIM card will be blocked. You must enter a PIN unlock key (PUK) to unblock the SIM or USIM card.
- If you block your SIM or USIM card by entering an incorrect PUK, bring the card to your service provider to unblock it.

Activate the mobile tracker

When someone inserts a new SIM or USIM card in your phone, the mobile tracker feature will automatically send the contact number to specified recipients to help you locate and recover your phone.

1. In Menu mode, select **Settings** → **Security** → **Mobile tracker**.
2. Enter your password and select **Confirm**.

3 Select **On** to turn on the mobile tracker.

4 Select the recipient field to open the recipient list.

5 Select the number input field.

6 Enter a phone number including a country code (with **+**) and select **Done**.

7 When you are finished setting the recipients, select **Save**.

8 Select the sender input field.

9 Enter a sender's name and select **Done**.

10 Select **Save** → **Accept**.

Enter text

You can enter text by selecting characters on the virtual keypad or by handwriting on the screen.

Change the text input method

When you tap the text input field, the input panel with the virtual keypad appears by default.

- To change the text input method, select and select an input method.
- To switch to ABC or T9 mode, select **T9** on the virtual keypad. When the T9 mode is active, the dot next to the T9 button turns on.
- To change case or switch to Number or Symbol mode, select **Abc**. Depending on your region, you may be able to access an input mode for your specific language.
- To clear your input, select .
- To insert a space, select .
- To change the input language, select the language button at the bottom of the screen.

Enter text using input methods

1 Change the text input method.

Input method	Function
Keypad	Select characters on the keypad.
Writing full sc.	Write anywhere on the screen.
Writing box 1/ Writing box 2	Write in the input boxes; You can enter numbers and symbols in the **?1** box in Writing box 1 mode.

2 Change the text input mode.

3 Select the appropriate virtual keys or write on the screen to enter text.

When entering text with the keypad, you can use the following modes:

Mode	Function
ABC	Select an appropriate virtual key until the character you want appears on the display.
T9	1. Select appropriate virtual keys to enter an entire word. 2. When the word displays correctly, select ␣ to insert a space. If the correct word does not display, select an alternative word from the list that appears or select Aa. You can add the word to the T9 dictionary by selecting **Add word** at the bottom of the alternative word list.

Mode	Function
Numeric	Select an appropriate virtual key to enter a number. You can enter numbers by tapping and holding a virtual key in ABC or T9 mode.
Symbols	1. Select ◀ or ▶ to scroll to a symbol set you want. 2. Select an appropriate virtual key to enter a symbol.

Access help information

Learn to access helpful information about key features of your phone.

1. In Idle mode, open the widget toolbar and select ?.
2. Select the help widget from the idle screen.
3. Rotate the phone anti-clockwise to landscape view.
4. Select a help topic to learn about an application or feature.
5. Scroll right to view more information.
   To return to the previous level, select .

Communication

Calling

Learn to use calling functions, such as making and answering calls using options available during a call, or customizing and using call-related features.

› Make and answer a call

Make a call

1 In Idle mode, select **Keypad** and enter an area code and a phone number.

2 Press the Dial key to dial the number. For a video call, select → **Video call**.

During a call, your phone automatically locks the touch screen to prevent accidental inputs. To unlock, press and hold the Lock key.

3 To end the call, press the Power/End key.

- Use the phonebook to save numbers you dial frequently. ► p. 48
- To quickly access the call log to redial the numbers you dialled recently, press the Dial key.

Answer a call

1 When a call comes in, press the Dial key.

When the phone is ringing, press the Volume key to adjust the volume, or press and hold the Volume key down to mute the ringtone.

2 To end the call, press the Power/End key.

Reject a call

When a call comes in, press the Power/End key. The caller will hear a busy tone.

You can set up a list of numbers to reject incoming calls automatically. ► p. 31

Call an international number

1. In Idle mode, select **Keypad** and tap and hold **0** to insert the **+** character.
2. Enter the complete number you want to dial (country code, area code and phone number), and then press the Dial key to dial the number.

› Use options during a voice call

You can use the following options while a voice call is in progress:

- To adjust the voice volume, press the Volume key up or down.
- To activate the speakerphone feature, select **Speaker** → **Yes**.

In noisy environments, you may have difficulty hearing some calls while using the speakerphone feature. For better audio performance, use the normal phone mode.

- To place a call on hold, select **Hold**. To retrieve a held call, select **Retrieve**.
- To dial a second call, place the first call on hold and then dial a new number. You must subscribe to the call waiting service to use this feature.
- To answer a second call, press the Dial key when a call waiting tone sounds. The first call is automatically placed on hold. You must subscribe to the call waiting service to use this feature.
- To switch between the two calls, select **Swap**.

› View and dial missed calls

Your phone will display calls you have missed on the display.

- When you have one missed call, select the call from the event alert widget and select **Voice call** to dial.
- When you have two missed calls or more, select the call from the event alert widget and select **Logs** → a missed call.

› Use additional features

You can use various other call-related features, such as auto rejection, fake calls, or Fixed Dialling Number (FDN) mode.

Set the auto rejection

Use the auto rejection to reject calls from certain numbers automatically. To activate the auto rejection and set up the reject list,

1. In Menu mode, select **Settings** → **Application settings** → **Call** → **All calls** → **Auto reject**.
2. Select **On** under **Activation**.
3. Select **Add number**.
4. Select the number input field, enter a number to reject, and select **Done** → **Save**.
5. To add more numbers, repeat steps 3-4.
6. Select the check boxes next to the numbers.
7. Select **Save**.

Make a fake call

1. In Menu mode, select **Settings** → **Application settings** → **Call** → **Fake call**.
2. Select **On** under **Activation**.

You can simulate fake incoming calls when you want to get out of meetings or unwanted conversations.

To make a fake call, press and hold the Volume key down in Idle mode. A fake call comes in after a specified length of time.

You can change the delay time before fake calls. In Menu mode, select **Settings** → **Application settings** → **Call** → **Fake call** → **Fake call timer**.

You can make fake calls appear more realistic by playing back a recorded voice. To record a voice,

1. In Menu mode, select **Settings** → **Application settings** → **Call** → **Fake call** → **Fake call voice**.
2. Select **On** under **Fake call voice**.
3. Select **Voice recording**.
4. Select ● to start recording.
5. Speak into the microphone.
6. When you are finished, select ■.
   The recorded voice plays.

Use Fixed Dialing Number (FDN) mode

In FDN mode, your phone will restrict outgoing calls, except for the numbers stored in the FDN list. You must first set up your FDN list in the phonebook to use FDN mode. ► p. 50

To activate FDN mode,

1. In Menu mode, select **Settings** → **Security**.
2. Select **On** under **Fixed dialling mode**.
3. Enter the PIN2 supplied with your SIM or USIM card and select **Confirm**.

Logs

Learn to view and manage logs of calls you have dialled, received, or missed and messages you have sent or recieved.

› View call and message logs

You can view logs of your calls and messages filtered by their types.

1. In Menu mode, select **Call log**.
2. Select the **All** drop-down menu and select a log type.
3. Select a log to view its details.

From the detail view, you can dial the number, send a message to the number or add the number to the phonebook or reject list.

View the log manager

From the log manager, you can check the amount of data or number of messages sent or received and the cost and duration of your calls.

1 In Menu mode, select **Call log** → **Call manager**.

2 Select an option you want.

Option	Function
Data counter	View the amount of data you have sent or received.
Message counter	View the number of messages you have sent or received.
Call cost	View cost records for your calls, such as the cost of the last call and the total cost of all calls. You can also set the currency and price per unit, or cost limit to restrict calls according to your calling plan; The cost counter may be unavailable depending on your SIM or USIM card.
Call time	View time data for your calls, such as the duration of the last call and the total duration of all calls.

You can reset the records in the log manager. From each screen, select the reset button.

Messages

Learn to create and send text (SMS), multimedia (MMS), or email messages, and view or manage messages you have sent or received.

You may incur additional charges for sending or receiving messages while outside your home service area. For details, contact your service provider.

› Send a text message

1. In Menu mode, select **Messages** → **Create message** → **Message**.
2. Select the recipient input field and select **Contacts**.
   You can enter a number manually or select one from the call log or groups by selecting another option.
3. Select the check boxes next to contacts and select **Add**.
4. Select **Tap to add text**.
5. Enter your message text and select **Done**.
6. Select **Send** to send the message.

› Set up an MMS profile

To send and receive multimedia messages, you must activate a connection profile for connecting to the MMS server. In addition to profiles that are preset by your service provider, you can add your own connection profile.

1. In Menu mode, select **Messages** → **Settings** → **Multimedia messages** → **Profiles**.
2. Select **Create**.
3. Customize the parameters for the connection profile.
4. When you are finished, select **Save**.

Send a multimedia message

1. In Menu mode, select **Messages** → **Create message** → **Message**.
2. Select the recipient input field and select **Contacts**.
   You can enter a number or email address manually or select one from the call log or groups by selecting another option.
3. Select the check boxes next to contacts and select **Add**.
   When you enter an email address, the phone will ask if you want to send a multimedia message. Select **OK** to confirm.
4. Select **Tap to add text**.
5. Enter your message text and select **Done**.
6. Select **Add media** and attach a file.
   You can select a file from the file list or capture a photo, video, or sound clip.
7. Select **Send** to send the message.

Set up an email account and profile

In addition to the email account predefined by your service provider, you can add your personal email accounts. Also, you can add your own connection profile for using email services.

Set up an email account

1. In Menu mode, select **Messages** → **Settings** → **Email** → **Email accounts**.
   For assistance with setting up your email account, select the **Email setup wizard**.
2. Select **Create**.
3. Customize the settings for the account.
4. When you are finished, select **Save**.

Set up an email profile

1. In Menu mode, select **Messages** → **Settings** → **Email** → **Profiles**.
2. Select **Create**.
3. Customize the network settings.
4. When you are finished, select **Save**.

› Send an email message

1. In Menu mode, select **Messages** → **Create message** → **Email**.
2. Select the recipient input field and select **Contacts**.
   You can enter an email address manually or select one from the call log or groups by selecting another option.
3. Select the check boxes next to contacts and select **Add**.
4. Select **Tap to add subject**, enter a subject, and select **Done**.
5. Select **Tap to add text**, enter your email text, and select **Done**.
6. Select **Add files** and attach a file.
   You can select a file from the file list or capture a photo, video, or sound clip.
7. Select **Send** to send the message.

› View a message

Messages you have received, sent or saved are sorted automatically into the following message folders.

- **Inbox**: Received text or multimedia messages
- **Email inbox**: Received email messages
- **Drafts**: Messages that you have saved for future use
- **Outbox**: Messages that are currently sending or waiting to be sent
- **Sentbox**: Sent messages.

View a text or multimedia message

1. In Menu mode, select **Messages** and select a message folder (inbox or sentbox).
2. Select a text or multimedia message.

You can view all text or multimedia messages sent to or received from a specific contact like a messenger. In Menu mode, select **Messages** → **Conversations** → a contact.

View an email message

1. In Menu mode, select **Messages** → **Email inbox**.
2. Select an email account.
3. Select **Download**.
4. Select an email or a header.
5. If you selected a header, select **Retrieve** to view the body of the email.

› Listen to voice mail messages

If you have set missed calls to be diverted to the voice mail server, callers may leave voice messages when you do not answer incoming calls. To access your voice mail box and listen to voice mail messages,

1. In Idle mode, select **Keypad**, and then tap and hold **1**.
2. Follow the instructions from the voice mail server.

You must save the voice mail server number before accessing the server. Your service provider can give you the number.

› Use message templates

Learn to create and use text and multimedia templates to quickly and easily create new messages.

Create a text template

1. In Menu mode, select **Messages** → **Templates** → **Text templates**.
2. Select **Create** to open a new template window.
3. Tap the input field, enter your text, and select **Done**.
4. Select **Save**.

You can now insert a text template in the text field while creating a text, multimedia, or email message by using the inserting option.

Create a multimedia template

1. In Menu mode, select **Messages** → **Templates** → **Multimedia templates**.
2. Select **Create** to open a new template window.
3. Create a multimedia message, with a subject and desired attachments, to use as your template. ► p. 35
4. Select **Save**.

You can now use a multimedia template to create a new multimedia message. From the template list, select next to the template to use. Your template will open as a new multimedia message.

› Create a folder to manage messages

Learn to create folders to manage your messages according to your preferences and needs.

1. In Menu mode, select **Messages** → **My folders**.
2. Select **Create folder**.
3. Enter a new folder name and select **Done**.

You can now move your important messages from the inbox or sentbox to a custom folder for easier management or preventing them from accidental deletion.

Send an SOS message

In case of an emergency, you can ask for help by sending an SOS message to specified recipients.

This feature may be unavailable depending on your region or service provider.

1. In Menu mode, select **Messages** → **SOS messages** → **Sending options**.
2. Select **On** to turn on the SOS messaging feature.
3. Select the recipient field to open the recipient list.
4. Select **Tap to add recipient**, enter a recipient number, and select **Done**. Skip to step 7.

   To select a number saved in your contact list, select to open the contact list and then continue with the next step.
5. Select contacts and select **Add**.
6. Select a phone number (if necessary).
7. When you are finished setting the recipients, select **Save**.
8. Select the **Repeat** drop-down menu and select the number of times to repeat the SOS message.
9. Select **Save** → **Yes**.

To send an SOS message, the touch screen and keys must be locked. Press the Volume key 4 times.

Once you send an SOS message, all phone functions will be suspended until you press the Power/End key or the Lock key.

Chat

1. In Menu mode, select **Chat**.
2. Select **OK** from the intro window.

   The first time you access the messenger, you will be prompted to confirm.
3. Enter your user ID and password and log in.
4. Chat with your family or friends instantly.

   - This feature may be unavailable depending on your region or service provider.
   - To change the language for the messenger, access the messenger and select **Menu** → **Settings**→ **Language**.

Entertainment

Camera

Learn how to capture and view photos and videos. You can capture photos at resolutions up to 1280 x 960 pixels (1.3 mega pixels) and videos at resolutions up to 176 x 144 pixels.

› Capture a photo

1 In Idle mode, press [📷] to turn on the camera.

2 Rotate the phone anti-clockwise to landscape view.

- Tap the screen to hide or display icons in the viewfinder.
- The memory capacity may differ depending on the shooting scene or shooting conditions.

3 Aim the lens at the subject and make any necessary adjustments.

4 Press the Volume key to zoom in or out.

5 Press [📷] to take a photo.
The photo is saved automatically.

After capturing photos, select ▶ to view the captured photos.

› Capture a photo in Smile shot mode

Your camera can recognize people's faces and help you capture photos of their smiling faces.

1 In Idle mode, press [📷] to turn on the camera.

2 Rotate the phone anti-clockwise to landscape view.

3 Select S → **Smile shot**.

4 Make any necessary adjustments.

5 Press [📷].

6 Aim the camera lens at your subject.

Your phone recognizes people in an image and detects their smiles. When the subject smiles, the phone automatically captures a photo.

Capture a series of photos

You can easily capture a series of photos of moving subjects. This is useful when you are photographing children at play or a sporting event.

1 In Idle mode, press [📷] to turn on the camera.

2 Rotate the phone anti-clockwise to landscape view.

3 Select [S] → **Continuous**.

4 Make any necessary adjustments.

5 Press and hold [📷]. The camera will continue to capture photos until you release [📷].

Capture a panoramic photo

You can capture wide panoramic photos using Panorama shooting mode. This mode is convenient for photographing landscapes.

1 In Idle mode, press [📷] to turn on the camera.

2 Rotate the phone anti-clockwise to landscape view.

3 Select [S] → **Panorama**.

4 Make any necessary adjustments.

5 Press [📷] to take the first photo.

6 Slowly move the phone in the direction you selected and align the frame with the viewfinder.

When you have aligned the frame and viewfinder, the camera will automatically capture the next photo.

7 Repeat step 6 to complete the panoramic photo.

Capture a mosaic photo

You can capture multiple images and automatically combine them into a mosaic.

1. In Idle mode, press [📷] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select [S] → **Mosaic**.
4. Select an image layout and press [📷].
5. Make any necessary adjustments.
6. Press [📷] to take photos for each segment.

Capture a photo with decorative frames

1. In Idle mode, press [📷] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select [S] → **Frames**.
4. Select a frame and press [📷].
5. Make any necessary adjustments.
6. Press [📷] to take the photo and automatically apply the decorative frame.

Capture a video

1. In Idle mode, press [📷] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select 📹 to switch to the camcorder.
4. Aim the lens at the subject and make any necessary adjustments.
5. Press the Volume key to zoom in or out.
6. Press [📷] to start recording.
7. Select ■ or press [📷] to stop recording.
   The video is saved automatically.

After capturing videos, select [▸] to view the captured videos.

Music

Learn to listen to your favorite music while on the go with the music player.

Add music files to your phone

Start by transferring files to your phone or memory card:

- Download from the wireless web. ► p. 53
- Download from a PC with the optional Samsung Kies. ► p. 63
- Receive via Bluetooth. ► p. 61
- Copy to your memory card. ► p. 63
- Synchronize with Windows Media Player 11. ► p. 64

Play music

After transferring music files to your phone or memory card,

1. In Menu mode, select **Music**.
2. Select a music category → a music file.
3. Control playback with the following icons:

Icon	Function
❚❚	Pause playback; Select ▶ to resume playback.
⏮	Skip backward; Scan backward in a file (tap and hold).
⏭	Skip forward; Scan forward in a file (tap and hold).
[1]	Activate Shuffle mode.
NORM [1]	Change the equalizer type.
A [1]	Change the repeat mode (off, repeating a file, or repeating all files).

1. These icons are shown when you tap the player screen.

› Create a playlist

1. In Menu mode, select **Music**.
2. Select **Playlists** → **Create**.
3. Select the text input field, enter a title for your new playlist, and select **Done**.
   To assign an image to the playlist, select the playlist image and select an image or capture a new photo.
4. Select **Save**.
5. Select the new playlist.
6. Select **Add** → **Tracks**.
   You can add all music files from another playlist by selecting **Playlists** and then a playlist.
7. Select the files you want to include and select **Add**.

Find music

Learn to access an online music service to get information about a song.

- This service is not available from some service providers.
- The database may not include information for all songs.

1. In Menu mode, select **Find music**.
2. Select **Find music** to connect to the server.
3. Select a connection profile to use.
4. When your phone is successfully registered, select ● to record a part of a song.
5. Follow the on-screen instructions to send the recording to the music information server.

FM radio

Learn to listen to music and news on the FM radio. To listen to the FM radio, you must connect the supplied headset, which serves as the radio antenna.

› Listen to the FM radio

1 Plug the supplied headset into the phone.

2 In Menu mode, select **FM radio**.

3 Select ▶ to turn on the FM radio.

4 Select **Yes** to start automatic tuning.
The FM radio scans and saves available stations automatically.

The first time you turn on the FM radio, you will be prompted to start automatic tuning.

5 Control the FM radio with the following icons:

Icon	Function
	Access the favorites list.
	Change the sound output (headset or phone's speaker).
	Turn off the FM radio; Select ▶ to turn on the FM radio.
	Change the frequency by 0.1 MHz; Search for an available radio station (tap and hold).

To get information about a song you hear on the FM radio, select **More** → **Find music**. ► p. 45

To add the current radio station to the favorites list, select **Add to Favourites**.

Save radio stations automatically

1. Plug the supplied headset into the phone.
2. In Menu mode, select **FM radio**.
3. Select **More** → **Self-tuning**.
4. Select **Yes** to confirm (if necessary).
   The FM radio scans and saves available stations automatically.

Games

Learn to use games and applications powered by award-winning Java technology.

The download of Java games or applications may not be supported depending on the software of the phone.

Download games and applications

1. In Menu mode, select **Games** → **More games**.
   Your phone connects to the website preset by your service provider.
2. Search for a game or application and download it to the phone.

This feature may be unavailabble depending on your region or service provider.

Play games or launch applications

1. In Menu mode, select **Games**.
2. Select a game or application from the list and follow the on-screen instructions.
   Select **More** to access a list of various options and settings for your game or application.

Personal information

Phonebook

Learn to create and manage a list of your personal or business contacts stored on the phone's memory or a SIM or USIM card. You can save names, mobile phone numbers, home phone numbers, email addresses, birthdays and more for your contacts.

› Create a contact

1. In Idle mode, select **Contacts** → **Create contact**.
2. Select **Phone** or **SIM**.
3. Enter contact information.

If you are saving the contact on a SIM or USIM card, you can save only the contact's name and a phone number.

4. Select **Save** to add the contact to memory.

You can also create a contact from the dialling screen.

1. In Idle mode, select **Keypad** and enter a phone number.
2. Select → **Save in Contacts** → **New**.
3. Select **Phone** or **SIM**.
4. Enter contact information.
5. Select **Save** to add the contact to memory.

› Find a contact

1. In Idle mode, select **Contacts**.
2. Select the search field, enter the first letters of the name you want, and select **Done**.
   You can also drag to select the first letter of the name.

3 Select the contact's name from the contact list.

Once you found a contact, you can:

- call the contact by pressing the Dial key.
- edit the contact information by selecting **Edit**.

Set a favorite number

1 In Idle mode, select **Contacts**.

2 Select the **Conta...** drop-down menu and select **Favourites**.

3 Select a location number → a contact.

The contact is saved to the favorite number list.

- Once you set a favorite number, you can dial the number by tapping and holding the corresponding location number on the dialing screen.
- The first 5 favorite numbers will be assigned to the favorite contacts on the widget toolbar.

Create a group of contacts

By creating groups of contacts, you can manage multiple contacts and send messages or email to an entire group. Start by creating a group.

1 In Idle mode, select **Contacts**.

2 Select the **Conta...** drop-down menu and select **Groups**.

3 Select **Create group**.

4 Select a name, caller ID photo, ringtone, and vibration type for the group.

5 Select **Save**.

› Create an FDN list

You can set up a list of contacts to be used in Fixed Dialing Number (FDN) mode that restricts outgoing calls if the feature is supported by your SIM or USIM card. The FDN list is saved on your SIM or USIM card.

1. In Idle mode, select **Contacts** → **More** → **FDN contacts**.
2. Select **Create FDN**.
3. Enter the PIN2 supplied with your SIM or USIM card and select **Confirm**.
4. Enter contact information.
5. Select **Save**.

To restrict outgoing calls to only those numbers saved in the FDN list, activate FDN mode. ► p. 32

Calendar

Learn to create and manage daily, weekly or monthly events.

› Create an event

1. In Menu mode, select **Calendar**.
2. Select **Create** → an event type.
3. Enter the details of the event as required.
4. Select **Save**.

› View events

To change the calendar view,

1. In Menu mode, select **Calendar**.
2. Select **More** → **View by day**, **View by week**, or **View by month**.

To view events of a specific date,

1. In Menu mode, select **Calendar**.
2. Select a date on the calendar. On the calendar, the dates with scheduled events are indicated with a triangle.
3. Select an event to view its details.

To view events by event types,

1. In Menu mode, select **Calendar**.
2. Select **Event list** → an event type.
3. Select an event to view its details.

Task

Learn to create a virtual task list and set alarms to remind yourself of important tasks or set priority.

› Create a task

1. In Menu mode, select **Task**.
2. Select **Create task**.
3. Enter the details of the task.
   To add detailed settings, select **Set details**.
4. Select **Save**.

› View tasks

1. In Menu mode, select **Task**.
2. Select the **Priority** drop-down menu and select a category (priority, status, or due date) to sort the tasks.
3. Select a task to view its details.

For completed tasks with an expired deadline, you can set their status to completed. You will not be reminded of those tasks any longer.

Memo

Learn to record important information to save and view at a later date.

Create a memo

1. In Menu mode, select **Memo**.
2. Select **Create memo**.
3. Enter your memo text and select **Done**.

View memos

1. In Menu mode, select **Memo**.
2. Select a memo to view its details.

Voice recorder

Learn to operate your phone's voice recorder. You can set voice memos as call or alarm ringtones.

Record a voice memo

1. In Menu mode, select **Voice recorder**.
2. Select ● to start recording.
3. Speak into the microphone.
4. When you are finished, select ■.
   Your memo is saved automatically.
5. To record more voice memos, select **Record** and repeat steps 2-4.

Play a voice memo

1. In Menu mode, select **Voice recorder**.
2. Select **My voice clips** to access the voice memo list.
3. Select a voice memo.
4. Control playback with the on-screen keys.

Web

Internet

Learn to access and bookmark your favorite web pages.

- You may incur additional charges for accessing the web and downloading media. For details, contact your service provider.
- The web browser menu may be labelled differently depending on your service provider.
- Available icons may vary depending on your region or service provider.

› Set up an internet profile

To access the network and connect to the internet, you must activate a connection profile. In addition to profiles that are preset by your service provider, you can add your own connection profile.

1. In Menu mode, select **Internet** → **Settings** → **Internet profiles**.
2. Select **Create**.
3. Customize the network settings.
4. When you are finished, select **Save**.

› Browse web pages

1. In Menu mode, select **Internet** → **Home** to launch a specified homepage.

   To access a specific web page, select **Enter URL**, enter the web address (URL) of the web page, and select **Go**.

2 Navigate web pages with the following icons:

Icon	Function
	Move backward or forward to web pages in history.
	Refresh the current web page.
	Change the view mode.
	Open a list of saved bookmarks.
	Change the orientation of the screen.
	Access a list of web browser options.

› Bookmark your favorite web pages

You can bookmark web pages you frequently visit for quick access. While navigating the web, select → **Add to Bookmarks** to bookmark the current web page.

If you know the web address of the web page, you can manually add a bookmark offline. To add a bookmark,

1 In Menu mode, select **Internet** → **Bookmarks**.
2 Select **Add**.
3 Enter a page title and a web address (URL).
4 Select **Save**.

RSS reader

Learn to use the RSS reader to receive the latest news and information from your favorite websites.

› Add an RSS feed address

1 In Menu mode, select **Internet** → **RSS feeds**.
2 Select **Add**.

3 Enter the address of an RSS feed and select **Done**.

4 Select **Subscribe Now**.

› Update and read RSS feeds

1 In Menu mode, select **Internet** → **RSS feeds**.

2 Select **Update** → feeds → **Update** → **Yes**.

3 Select a feed category → an updated feed.

The auto update feature sets the phone to automatically update RSS feeds at specified intervals. You can activate the auto update feature by selecting **Internet** → **Settings** → **RSS update**. Activating the auto update feature increase the amount of data downloaded and may incur additional charges.

Samsung Apps

Learn to download a variety of media files, such as wallpapers, ringtones, games, music, and video clips from the Samsung Apps WAP site.

1 In Menu mode, select **Samsung Apps**.

2 Search for and download media files to the phone as desired.

- As a result of the Digital Rights Management (DRM) system, some of the media items you download from the internet or receive by multimedia messages may require a licence key to access them. You can acquire the key from the website which owns the rights to the content.
- This feature may be unavailable depending on your region or service provider.

Google

Learn to use various Google services, such as search and mail services.

- Some services may be unavailable depending on your region or service provider.
- The steps you must follow to use this feature may differ depending on your region or service provider.

› Use the Google Search service

1. In Menu mode, select **Google** → **Search**.
2. Select the search field.
3. Enter a keyword and select **Search**.

› Use the Google Mail service

You can access your Google Mail account and send or read email messages on your phone.

1. In Menu mode, select **Google** → **Mail**.
2. Enter your user ID and password and log in.
3. Send or receive emails.

Synchronize

Learn to synchronize contacts, calendar events, tasks, and memos with the web server you have specified.

› Set up a synchronization profile

1. In Menu mode, select **Synchronise**.
2. Select **Add** and specify the profile options.
3. When you are finished, select **Save**.

Start synchronization

1. In Menu mode, select **Synchronise**.
2. Select a synchronization profile.
3. Select **Continue** to start synchronization with the web server you have specified.

ActiveSync

Learn to synchronize personal data, such as emails, contacts, calendar events, and tasks, between your phone and your Microsoft Exchange server or Google account.

- Google Sync does not support task synchronization.
- You can use the Microsoft Exchange ActiveSync® feature only with services that are licensed by Microsoft Corporation.
- You may incur additional charges for accessing the server.

Set up a Microsoft Exchange server and profile

1. In Menu mode, select **ActiveSync**.
2. Specify Microsoft Exchange server settings.
3. Select **Save**.
4. Specify an email connection profile.
5. When you are finished, select **Save**.
6. Select a synchronization profile.
   Synchronization will begin with the Microsoft Exchange server you have specified.

› Start synchronization

After configuring sync settings for each data type, you can synchronize your data with the Exchange server (either all data at the same time or email only).

To synchronize all items,

1. In Menu mode, select **ActiveSync**.
2. Select **Sync**.

If you synchronize all items, you may incur charges for updating items unnecessarily.

To synchronisze only your emails,

1. In Menu mode, select **ActiveSync**.
2. Select **Email** → **Inbox** → **Sync** → **Email** → **Select**, or select **Outbox** → **Sync**.

Communities

Learn to share your photos and videos with other people on community websites and blogs, such as MySpace or Facebook.

- This feature may be unavailable depending on your region or service provider.
- You can upload files only in jpg and mp4 format to the web.

› Set your favorite website or blog list

1. In Menu mode, select **Commun.**
2. Select **Yes** to set your favorite website or blog list (if necessary).
3. Select **Accept** to confirm that you agree to the general disclaimer.

The first time you access the menu, you will be prompted to confirm.

4 Select the website or blog you want to add and select **Save**.

If you selected **Update lists**, new websites or blogs are added to the list automatically.

Share a file

To upload or view photos and videos, you must have accounts with photo sharing websites and blogs.

1 In Menu mode, select **Commun.**

2 Select **Upload to web**.

3 Select a website or blog you want to access.

4 Enter your user ID and password and log in.

5 To upload files, select **Tap to add** and select a media file.

6 Enter the post details and select **Upload**.

Connectivity

Bluetooth

Bluetooth is a short-range wireless communications technology capable of exchanging information over a distance of about 10 meters (30 feet) without requiring a physical connection.

- Samsung is not responsible for the loss, interception, or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured. If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your phone.

› Turn on the Bluetooth wireless feature

1. In Menu mode, select **Bluetooth**.
2. Select the Bluetooth icon in the top of the screen.

To allow other devices to locate your phone, select **More** → **Settings** → **On** under **My phone's visibility** → a visibility option → **Save**. If you selected **Custom**, set duration that your phone is visible.

› Find and pair with other Bluetooth-enabled devices

1. In Menu mode, select **Bluetooth** → **Search**.
2. Select a device.

3 Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and select **Done**. Alternatively, select **Yes** to match the PIN between your phone and the device.

When the owner of the other device enters the same PIN or accepts the connection, pairing is complete. If the pairing is successful, the device will automatically search for available services.

Once the phone is paired with another Bluetooth-enabled device, the device icon will turn blue. Select a paired device and use the following options:

- To browse the file directory of the device and exchange files, select **Browse files**.
- To change the device name, select **Rename**.
- To allow the device to access your phone without your confirmation, select **Authorise device**.

To check Bluetooth services available on your phone and information about the services, select **More** → **Bluetooth services**.

Send data using the Bluetooth wireless feature

1 Select a file or item, such as a contact, calendar event, memo, task, or media file, from an appropriate application or **My files**.

2 Select **Send via** → **Bluetooth**, or select **More** → **Send namecard via** → **Bluetooth**.

Receive data using the Bluetooth wireless feature

1 Enter the PIN for the Bluetooth wireless feature and select **OK** (if necessary).

2 Select **Yes** to confirm that you are willing to receive data from the device (if necessary).

Received data is saved to an appropriate application or folder according to its type. For example, a music or sound clip is saved to the sound folder and a contact to the phonebook.

Print data using the Bluetooth wireless feature

1. Select a file or item, such as a message, contact, calendar event or image, from an appropriate application.
2. Select **More** → **Print via** → **Bluetooth**, or select **More** → **Print via Bluetooth**.
3. Search for and pair with a Bluetooth-enabled printer.
4. When connected to the printer, customize print options and print the data.

Use Remote SIM mode

In Remote SIM mode, you can make or answer calls only with a connected Bluetooth hands-free car kit via the SIM or USIM card on your phone.

To activate Remote SIM mode,

1. In Menu mode, select **Bluetooth** → **More** → **Settings**.
2. Select **On** under **Remote SIM mode** → **Save**.

To use Remote SIM mode, start the Bluetooth connection from a Bluetooth hands-free car kit.

PC connections

Learn to connect your phone to a PC with the supplied PC data cable in various USB connection modes.

› Connect with Samsung Kies

Ensure that Samsung Kies is installed on your PC. You can download the program from the Samsung website (www.samsungmobile.com).

1. In Menu mode, select **Settings** → **Phone settings** → **PC connections** → **Samsung Kies** → **Save**.
2. Press the Power/End key to return to Idle mode.
3. Using an optional PC data cable, connect the multifunction jack on your phone to a PC.
4. Run Samsung Kies and copy data and files.

› Connect as a mass storage device

You can connect your phone to a PC as a removable disk and access the file directory. If you insert a memory card in the phone, you can also access the file directory of the memory card by using the phone as a memory card reader.

1. If you want to transfer files from or to a memory card, insert a memory card into the phone.
2. In Menu mode, select **Settings** → **Phone settings** → **PC connections** → **Mass storage** → **Save**.
3. Press the Power/End key to return to Idle mode.
4. Using an optional PC data cable, connect the multifunction jack on your phone to a PC.
   When connected, a pop-up window will appear on the PC.
5. Open the folder to view files.
6. Copy files from the PC to the memory card.

Synchronize with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1. In Menu mode, select **Settings** → **Phone settings** → **PC connections** → **Media player** → **Save**.
2. Press the Power/End key to return to Idle mode.
3. Using an optional PC data cable, connect the multifunction jack on your phone to a PC with Windows Media Player installed.

   When connected, a pop-up window will appear on the PC.
4. Open Windows Media Player to synchronize music files.
5. Edit or enter your phone's name in the pop-up window (if necessary).
6. Select and drag the music files you want to the sync list.
7. Start synchronization.

Tools

Alarms

Learn to set and control alarms for important events.

› Set a new alarm

1. In Menu mode, select **Alarms**.
2. Select **Create alarm**.
3. Set alarm details.
4. When you are finished, select **Save**.

The auto power-up feature sets the phone to automatically turn on and sound the alarm at the designated time when the phone is turned off.

› Stop an alarm

When the alarm sounds,

- Tap and hold **Stop** to stop the alarm.
- Tap and hold **Snooze** to silence the alarm for the snooze period.

› Deactivate an alarm

1. In Menu mode, select **Alarms**.
2. Select **Off** under the alarm you want to deactivate.

Calculator

1. In Menu mode, select **Calculator**.
2. Use the keys that correspond to the calculator display to perform basic mathematical operations.

Convertor

1. In Menu mode, select **Convertor** → a conversion type.
2. Enter the currencies or measurements and units in the appropriate fields.

Image editor

You can edit images and apply fun effects.

› Apply effects to images

1. In Menu mode, select **Image editor**.
2. Rotate the phone anti-clockwise to landscape view.
3. Select **Tap here to open** and rotate the phone clockwise to portrait view.
4. Select a folder → an image → **Add**.
5. Rotate the phone anti-clockwise to landscape view.
6. Select **Effects** → an effect option (filter, style, warp, or partial blur).
7. Select a variation of the effect to apply and select **OK**.

   To apply a blur effect to a specific area of an image, draw a rectangle and select **OK** twice.
8. When you are finished, select **File** → **Save as**.
9. Select a memory location (if necessary) → **Select**.
10. Rotate the phone clockwise to portrait view.
11. Enter a new file name for the image and select **Done**.

› Adjust an image

1. Open an image to edit.
2. Select **Adjust** → an adjustment option (brightness, contrast, or color).

   To adjust the image automatically, select **Auto level**.

3 Adjust the image as desired and select **OK**.

4 Save the edited image with a new file name.

Transform an image

1 Open an image to edit.

2 Select the arrow at the bottom right of the screen.

3 Select (for rotate) or (for resize).

4 Rotate or resize the image as desired and select **OK**.

5 Save the edited image with a new file name.

Crop an image

1 Open an image to edit.

2 Select the arrow at the bottom right of the screen.

3 Select .

4 Move or resize the rectangle over the area you want to crop and select **OK** twice.

5 Save the edited image with a new file name.

Insert a visual feature

1 Open an image to edit.

2 Select the arrow at the bottom right of the screen.

3 Select , , , or .

4 Select a visual feature (image, emoticon, or clip art), or enter text and select **Done**.

5 Move or resize the visual feature and select **OK**.

6 Save the edited image with a new file name.

My files

Learn to quickly and easily access all of your images, videos, music, sound clips, and other types of files stored on the phone or a memory card.

View a file

1. In Menu mode, select **My files** → a file type.
   Folders or files on the memory card are indicated by a memory card icon.
2. Select a folder → a file.

You can use the following options while viewing a file:

- To print an image using a USB connection, select **More** → **Print via** → **USB**.
- To print an image using the Bluetooth wireless feature, select **More** → **Print via** → **Bluetooth**.
- To set an image as a background image for the idle screen, select **More** → **Set as** → **Wallpaper**.
- To set a sound clip as ringtones for incoming calls, during playback, select **Set as** → **Voice call ringtone** or **Video call ringtone**.

Stopwatch

1. In Menu mode, select **Stopwatch**.
2. Select **Start** to begin the stopwatch.
3. Select **Lap** to record lap times.
4. When you are finished, select **Stop**.
5. Select **Reset** to clear recorded times.

Timer

1. In Menu mode, select **Timer**.
2. Set the length of time to count down.
3. Select **Start** to begin the countdown.
   You can now use other functions with the timer counting down in the background. Press the Back key or the Power/End key and access another application.
4. When the timer expires, select **Stop** to stop the alert.

World clock

Learn to view the time in another region and set world clocks to appear on your display.

› Create a world clock

1. In Menu mode, select **World clock**.
2. Select → **Add**.
3. Select a time zone.
   To apply the summer time to the clock, select Off.
4. Select **OK** to create your world clock.
   The world clock is set as the second clock.
5. To add more world clocks, select **Add** and repeat steps 3-4.

› Add a world clock to your display

With the dual clock widget, you can view clocks with two different time zones on your display.

After you have created world clocks,

1. In Menu mode, select **World clock**.
2. Select **Set as 2nd clock**.
3. Select the world clock to add to the dual clock widget.
4. Select **Set**.

Settings

Access the Settings menu

1. In Menu mode, select **Settings**.
2. Select a setting category and select an option.
3. Customize the setting and select **Save** or **Set**.

Phone profiles

Select a sound profile to use or customize sound options in profiles as desired.

Display and light

Access and alter the following settings to control the display and usage of light on your phone.

- **Wallpaper**: Select a background image for the idle screen.
- **My theme**: Select a color theme for the menu screens.
- **Widget**: Select widgets to be available on the toolbar.
- **Font type**: Select a font type for the display text.
- **Greeting message**: Edit the message that greets you when you turn on your phone.
- **Brightness**: Set the brightness of the display.
- **Backlight time**: Set the length of time the phone waits before turning off the display's backlight.

Time and date

Access and alter the following settings to control how time and date are displayed on your phone.

Phone settings

Access and alter the following settings to control general settings for your phone:

- **Language**: Select a language to use on the phone's display and text input.
- **Vibration feedback**: Adjust the intensity of the vibration that results from tapping the screen.
- **Calibration**: Realign your touch screen's sensors with your inputs.
- **Missed caller information**: Set whether or not to display the caller information for incoming calls and messages.
- **PC connections**: Set a USB mode to be activated when you connect the phone to a PC. ► p. 63
- **Licence settings**: Customize the settings related with license keys, such as tracking, alert for expiry, or downloading in foreign networks.

Smart unlock

Activate the gesture unlock feature that allows you to unlock the touch screen and keys by drawing a specified character. ► p. 24

Touch panel

Set the phone to automatically lock the touch screen and the keys when you do not use the phone for a specified period.

Application settings

Access and alter the following settings to control your phone's applications:

- **Call**: Customize the settings for calling features.
- **Messages**: Customize the settings for messaging features.

- **Contacts**: Customize the settings for the phonebook.
- **Calendar**: Customize the settings for the calendar.
- **Internet**: Select a connection profile to use for accessing the internet. ► p. 53
- **Media player**: Customize the settings for the music player and video player.

Security

Access and alter the following settings to secure your phone and data:

- **Phone lock**: Activate or deactivate the phone lock feature to require a phone password before using the phone.
- **SIM lock**: Activate or deactivate the SIM lock feature to require the SIM password when you change the SIM or USIM card.
- **PIN lock**: Activate or deactivate the PIN lock feature to require the PIN before using the phone.
- **Privacy lock**: Make various types of data private; To access private data, you must enter your phone password.
- **Fixed dialling mode**: Activate or deactivate FDN mode to restrict calls to number in the FDN list.
- **Change password**: Change the phone password.
- **Change PIN**: Change the PIN used to access SIM or USIM data.
- **Change PIN2**: Change the PIN2, which is used to protect the primary PIN.
- **Mobile tracker**: Activate or deactivate the mobile tracker feature which helps you locate your phone when it is lost or stolen. ► p. 25

Network settings

Access or alter the following settings to control how your phone selects and connects to networks:

- **Network selection**: Set the network selection method to automatic or manual.
- **Network mode**: Select a network band.
- **Connections**: Set up connection profiles to use for network features.
- **Certificates**: View certificates required for network services.
- **Preferred networks**: Set up a list of networks you prefer. Your phone will connect to these networks first when searching for available networks.

Memory settings

Access and alter the following settings to control your phone's memory use:

- **Clear memory**: Erase the selected data from your phone's memory.

  This will permanently erase all selected data from the phone's memory.
- **Memory card settings**: Access details about your memory card. You can also format the memory card or change the memory card's name.
- **Default memory**: Select the default memory location to use when transferring data, capturing images and videos, or recording voice memos.
- **Memory status**: View the used and available memory for various types of files.

Reset settings

Reset various settings to the factory default values. Select which settings to reset. You must enter your phone password to reset the settings.

Troubleshooting

When you turn on your phone or while you are using the phone, it prompts you to enter one of the following codes:

Code	Try this to solve the problem:
Password	When the phone lock feature is enabled, you must enter the password you set for the phone.
PIN	When using the phone for the first time or when the PIN requirement is enabled, you must enter the PIN supplied with the SIM card. You can disable this feature by using the **PIN lock** menu.
PUK	Your SIM card is blocked, usually as a result of entering your PIN incorrectly several times. You must enter the PUK supplied by your service provider.
PIN2	When you access a menu requiring the PIN2, you must enter the PIN2 supplied with the SIM card. For details, contact your service provider.

Your phone displays "Service unavailable" or "Network error"

- When you are in areas with weak signals or poor reception, you may lose reception. Move to another area and try again.
- You cannot access some options without a subscription. Contact your service provider for more details.

The touch screen responds slowly or improperly

If your phone has a touch screen and the touch screen is not responding properly, try the following:

- Remove any protective covers from the touch screen. Protective covers may prevent the phone from recognizing your inputs and are not recommended for touch screen phones.
- Depending on the type of touch screen on your phone, only certain inputs may be recognized. Try tapping an icon with your fingertip, your fingernail, or a stylus.
- Ensure that your hands are clean and dry when tapping the touch screen.
- Restart your phone to clear any temporary software bugs.
- Ensure that your phone software is upgraded to the latest version.
- If the touch screen is scratched or damaged, take it to your local Samsung Service Center.

Calls are being dropped

When you are in areas with weak signals or poor reception, you may lose your connection to the network. Move to another area and try again.

Outgoing calls are not connected

- Ensure that you have pressed the Dial key.
- Ensure that you have accessed the right cellular network.
- Ensure that you have not set call barring for the phone number you are dialing.

Incoming calls are not connected

- Ensure that your phone is turned on.
- Ensure that you have accessed the right cellular network.
- Ensure that you have not set call barring for the incoming phone number.

Others cannot hear you speaking on a call

- Ensure that you are not covering the built-in microphone.
- Ensure that the microphone is close to your mouth.
- If using a headset, ensure that it is properly connected.

Audio quality is poor

- Ensure that you are not blocking the phone's internal antenna.
- When you are in areas with weak signals or poor reception, you may lose reception. Move to another area and try again.

When dialing from contacts, the call is not connected

- Ensure that the correct number is stored in the contact list.
- Re-enter and save the number, if necessary.
- Ensure that you have not set call barring for the contact's phone number.

The phone beeps and the battery icon flashes

Your battery is low. Recharge or replace the battery to continue using the phone.

The battery does not charge properly or the phone turns off

- The battery terminals may be dirty. Wipe both gold-colored contacts with a clean, soft cloth and try charging the battery again.
- If the battery will no longer charge completely, dispose of the old battery properly and replace it with a new battery (refer to your local ordinances for proper disposal instructions).

Your phone is hot to the touch

When you use applications that require more power or use applications on your phone for an extended period of time, your phone may feel hot to the touch. This is normal and should not affect your phone's lifespan or performance.

Safety and usage information

This safety and usage information should be followed to safely use your phone.

Safety warnings

Keep your phone away from small children and pets

Keep your phone and all accessories out of the reach of small children or animals. Small parts may cause choking or serious injury if swallowed.

Protect your hearing

Excessive exposure to sound at high volumes can cause hearing damage. Always turn the volume down before plugging the earphones into an audio source and use only the minimum volume setting necessary to hear your conversation or music.

Install mobile phones and equipment with caution

Ensure that any mobile phones or related equipment installed in your vehicle are securely mounted. Avoid placing your phone and accessories near or in an air bag deployment area. Improperly installed wireless equipment can cause serious injury when air bags inflate rapidly.

Handle and dispose of batteries and chargers with care

- Use only Samsung-approved batteries and chargers specifically designed for your phone. Incompatible batteries and chargers can cause serious injuries or damage to your phone.
- Never dispose of batteries or phones in a fire. Follow all local regulations when disposing of used batteries or phones.
- Never place batteries or phones on or in heating devices, such as microwave ovens, stoves, or radiators. Batteries may explode when overheated.
- Never crush or puncture the battery. Avoid exposing the battery to high external pressure, which can lead to an internal short circuit and overheating.

Avoid interference with pacemakers

Maintain a minimum of 15 cm (6 inches) between mobile phones and pacemakers to avoid potential interference, as recommended by manufacturers and the independent research group, Wireless Technology Research.

If you have any reason to suspect that your phone is interfering with a pacemaker or other medical device, turn off the phone immediately and contact the manufacturer of the pacemaker or medical device for guidance.

Turn off the phone in potentially explosive environments

Do not use your phone at refueling points (service stations) or near fuels or chemicals. Turn off your phone whenever directed by warning signs or instructions. Your phone could cause explosions or fire in and around fuel or chemical storage and transfer areas or blasting areas. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the phone, its parts, or accessories.

Reduce the risk of repetitive motion injuries

While using your phone, hold the phone with a relaxed grip, press the keys lightly, use special features that reduce the number of keys you have to press (such as templates and predictive text), and take frequent breaks.

Do not use the phone if the screen is cracked or broken

Broken glass or acrylic could cause injury to your hand and face. Bring the phone to a Samsung service center to replace the screen. Damage caused by careless handling will void your manufacturer's warranty.

Safety precautions

Drive safely at all times

Avoid using your phone while driving and obey all regulations that restrict the use of mobile phones while driving. Use hands-free accessories to increase your safety when possible.

Follow all safety warnings and regulations

Comply with any regulations that restrict the use of a mobile phone in a certain area.

Use only Samsung-approved accessories

Using incompatible accessories may damage your phone or cause injury.

Turn off the phone near medical equipment

Your phone can interfere with medical equipment in hospitals or health care facilities. Follow all regulations, posted warnings, and directions from medical personnel.

Turn off the phone or disable the wireless functions when in an aircraft

Your phone can cause interference with aircraft equipment. Follow all airline regulations and turn off your phone or switch to a mode that disables the wireless functions when directed by airline personnel.

Protect the phone and batteries from damage

- Avoid exposing your phone and batteries to very cold or very hot temperatures (below 0° C/32° F or above 45° C/113° F).
- Extreme temperatures can cause the deformation of the phone and reduce the charging capacity and life of your phone and batteries.
- Prevent batteries from contacting metal objects, as this can create a connection between the + and - terminals of your batteries and lead to temporary or permanent battery damage.
- Never use a damaged charger or battery.

Handle your phone carefully and sensibly

- Do not disassemble your phone due to a risk of electric shock.
- Do not allow your phone to get wet—liquids can cause serious damage and will change the color of the label that indicates water damage inside the phone. Do not handle your phone with wet hands. Water damage to your phone can void your manufacturer's warranty.
- Avoid using or storing your phone in dusty, dirty areas to prevent damage to moving parts.
- Your phone is a complex electronic device—protect it from impacts and rough handling to avoid serious damage.
- Do not paint your phone, as paint can clog moving parts and prevent proper operation.
- If your phone has a camera flash or light, avoid using it close to the eyes of children or animals.
- Your phone may be damaged by exposure to magnetic fields. Do not use carrying cases or accessories with magnetic closures or allow your phone to come in contact with magnetic fields for extended periods of time.

Avoid interference with other electronic devices

Your phone emits radio frequency (RF) signals that may interfere with unshielded or improperly shielded electronic equipment, such as pacemakers, hearing aids, medical devices, and other electronic devices in homes or vehicles. Consult the manufacturers of your electronic devices to solve any interference problems you experience.

Important usage information

Use your phone in the normal position

Avoid contact with your phone's internal antenna.

Allow only qualified personnel to service your phone

Allowing unqualified personnel to service your phone may result in damage to your phone and will void your manufacturer's warranty.

Ensure maximum battery and charger life

- Avoid charging batteries for more than a week, as overcharging may shorten battery life.
- Over time, unused batteries will discharge and must be recharged before use.
- Disconnect chargers from power sources when not in use.
- Use batteries only for their intended purpose.

Handle SIM cards or memory cards with care

- Do not remove a card while the phone is transferring or accessing information, as this could result in loss of data and/or damage to the card or phone.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.

- Do not touch gold-colored contacts or terminals with your fingers or metal objects. If dirty, wipe the card with a soft cloth.

Ensure access to emergency services

Emergency calls from your phone may not be possible in some areas or circumstances. Before traveling in remote or undeveloped areas, plan an alternate method of contacting emergency services personnel.

Specific Absorption Rate (SAR) certification information

Your device conforms to U.S. Federal Communications Commission (FCC) standards that limit human exposure to radio frequency (RF) energy emitted by radio and telecommunications equipment. These standards prevent the sale of mobile phone that exceeds a maximum exposure level (known as the Specific Absorption Rate, or SAR) of 1.6 watts per kilogram of body tissue.

During testing, the maximum SAR values recorded for this model were:

Network Frequency	Specific Absorption Rate (W/kg)	
	Held to ear	Worn on body[1]
GSM850 (1g)	0.99	1.08
GSM1900 (1g)	0.74	0.19

1. When used with accessories that contain no metal and provide at least 1.5 cm separation between the phone (including the antenna, whether extended or retracted) and the wearer's body.

In normal use, the actual SAR is likely to be much lower, as the phone has been designed to emit only the RF energy necessary to transmit a signal to the nearest base station. By automatically emitting lower levels when possible, your phone reduces your overall exposure to RF energy.

The FCC has granted an Equipment Authorization for this model phone based on the compliance of all reported SAR levels with the FCC RF exposure guidelines. The authorization can be found on the FCC Office of Engineering and Technology website at http://www.fcc.gov/oet/ea (search for grantee code A3L and product code GT-S3370L).

Disclaimer

Some content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal noncommercial use. You may not use any content or services in a manner that has not been authorized by the content owner or service provider. Without limiting the foregoing, unless expressly authorized by the applicable content owner or service provider, you may not modify, copy, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium any content or services displayed through this device.

"THIRD PARTY CONTENT AND SERVICES ARE PROVIDED "AS IS." SAMSUNG DOES NOT WARRANT CONTENT OR SERVICES SO PROVIDED, EITHER EXPRESSLY OR IMPLIEDLY, FOR ANY PURPOSE. SAMSUNG EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SAMSUNG DOES NOT GUARANTEE THE ACCURACY, VALIDITY, TIMELINESS, LEGALITY, OR COMPLETENESS OF ANY CONTENT OR SERVICE MADE AVAILABLE THROUGH THIS DEVICE AND UNDER NO CIRCUMSTANCES, INCLUDING NEGLIGENCE, SHALL SAMSUNG BE LIABLE, WHETHER IN CONTRACT OR TORT, FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, ATTORNEY FEES, EXPENSES, OR ANY OTHER DAMAGES ARISING OUT OF, OR IN CONNECTION WITH, ANY INFORMATION CONTAINED IN, OR AS A RESULT OF THE USE OF ANY CONTENT OR SERVICE BY YOU OR ANY THIRD PARTY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES."

Third party services may be terminated or interrupted at any time, and Samsung makes no representation or warranty that any content or service will remain available for any period of time. Content and services are transmitted by third parties by means of networks and transmission facilities over which Samsung has no control. Without limiting the generality of this disclaimer, Samsung expressly disclaims any responsibility or liability for any interruption or suspension of any content or service made available through this device.

Samsung is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services should be made directly to the respective content and service providers.

Index

access codes 74

alarms
- creating 65
- deactivating 65
- stopping 65

auto rejection 31

battery
- charging 9
- installing 7

Bluetooth
- activating 60
- finding and pairing with devices 60
- printing data 62
- receiving data 61
- Remote SIM mode 62
- sending data 61

brightness, display 23

calculator 65

calendar
- creating events 50
- viewing events 50

call cost 33

call log 32

calls
- answering 29
- international numbers 30
- making 29
- making fake 31
- rejecting 29
- using options during voice 30
- viewing missed 30

call time 33

camera
- capturing photos 41
- capturing videos 43

comminities
- setting websites 58
- sharing files 59

contacts
- creating 48
- finding 48

convertor 66

downloads
- Java games 47

media files 55
email
sending 36
setting accounts 35
setting profiles 36
viewing 37
fake calls 31
FDN mode
activating 32
creating FDN contacts 50
file manager 68
fixed dialing number mode 32
FM radio
listening to 46
saving stations 47
Google
mail 56
search 56
hand strap 13
help 28
image editor
adjusting 66
applying effects 66
internet
see web browser
Java games
downloading 47
playing 47
key tone
volume 22
memory card
formatting 12
inserting 11
removing 12
memos
creating 52
viewing 52
menu screen 18
message log 32
messages
accessing voice mail 37
managing 38
sending email 36
sending multimedia 35
sending SOS 39
sending text 34
setting email acounts 35
setting email profiles 36
setting MMS profiles 34
using templates 37
viewing email 37
viewing multimedia 36
viewing text 36

mobile tracker 25
multimedia messages
sending 35
setting profiles 34
viewing 37
multi-tasking 19
music
finding 45
playing 44
music player
adding files 44
creating playlists 45
playing music 44
PC connections
mass storage 63
Samsung Kies 63
Windows Media Player 64
phone
customizing 21
indicator icons 16
keys 15
layout 14
locking 24
settings 70
turning on or off 14
phonebook
creating contacts 48
creating FDN contacts 50
creating groups 49
finding contacts 48
setting favorite numbers 49
phone lock 24
photos
capturing 41
capturing divided 43
capturing in smile shot 41
capturing panoramic 42
capturing with frames 43
capuring a series 42
editing 66
setting wallpaper 68
viewing 68
PIN lock 25
RSS reader 54
silent profile 22
SIM card
installing 7
locking 25
SOS messages 39
sound profiles 22
stopwatch 68

synchronisation
with an Exchange server 57
with a web server 56
with Windows Media Player 64
task manager 19
tasks
creating 51
viewing 51
text input 26
text memos 52
text messages
sending 34
viewing 37
time and date, set 21
timer 69
touch screen
calibrating 23
locking 18
unlocking with gestures 24
using 17
unpack 7
USIM card
installing 7
locking 25
video calls
answering 29
making 29
videos
capturing 43
playing 68
voice calls
answering 29
making 29
using options 30
voice mail 37
voice memos
playing 52
recording 52
voice recorder 52
wallpaper 23
web browser
adding bookmarks 54
browsing web pages 53
setting profiles 53
wigets
accessing 20
customizing the toolbar 21
downloading 21
Windows Media Player 64
world clock
creating 69
setting dual display 69